

Introduction

This manuscript reports research performed for NASA-MSFC during the period from February 1 to December 31, 1991 under Contract #NAS8-36955-114. The objective of this project was to investigate the feasibility of using frequency response techniques for enhancing destructive physical analysis and for nondestructive testing of aerospace battery electrodes. Nickel, cadmium, silver and zinc electrodes were tested by imposing alternating current upon the electrodes and measuring the magnitude and phase of the response voltage. This yields an impedance spectrum for the battery electrode from which electrochemical kinetic, double layer capacitance and mass transfer effects can be characterized. Frequencies from 10 kHz to 0.1 mHz were used in the testing.

Experimental

Figure 1 shows a diagram of the experimental apparatus. The centerpiece is a Schlumberger Model 1255 Frequency Response Analyser (FRA) and Model 1250 Electrochemical Interface (EI). The FRA contains a signal generator, the output of which can modulate the voltage or current output of the EI. The FRA also has two signal inputs which are connected to the two analog outputs of the EI, proportional to the cell current and the electrode potential.

The battery electrodes were placed in prismatic cells fabricated from plexiglass. These cells typically contained one working electrode and one or two counterelectrodes. The working electrode potential was measured relative to a reference electrode that was also in the cell. Only a small amount of current, on the order of microamperes, is drawn




Figure 1. Diagram of the experimental apparatus.

from the reference electrode during potential measurements, hence the working electrode polarization can be measured without interference from the counterelectrode. A silver reference electrode was used for silver and zinc working electrode measurements while a nickel reference electrode was used for nickel and cadmium electrode measurements.

The FRA and EI were controlled by an Apple II computer through a GPIB interface. Programs written in Applesoft Basic were used to control the amplitude and frequency during logarithmic sweeps of the working electrode impedance versus frequency, and to control the EI during charge and discharge of the cells. The results were displayed on the computer screen and recorded in a notebook for processing. Bode magnitude plots (impedance magnitude vs. log frequency) and Bode angle plots (impedance phase angle vs. log frequency) were used to represent the data.

Frequency response analysis is valid only for linear systems, but electrochemical parameters such as interfacial resistance, double-layer capacitance and diffusion (Warburg) impedance are strong functions of potential. Hence, it is important that the amplitude of the voltage response be small. Each of the above named impedances can be treated as constant if the voltage amplitude driving current through that impedance does not exceed 5 mV. The computer programs were written so that the total working electrode voltage amplitude was about 5 mV so that the amplitude through the individual impedances would be no larger than this maximum permissible value.

Mathematical Modeling

This section will briefly summarize the modeling techniques for analyzing impedance data. More complete presentations can be found in the literature. Two techniques are reported- equiva-

MacDonald, 1991). Two techniques are reported- equivalent circuit analysis and finite difference numerical analysis. Most of the work in this project used the first technique, but work with the second technique was begun.

Equivalent Circuit Analysis- The traditional approach to electrochemical impedance data is to model it in terms of equivalent electrical circuit elements, fitting the experimental data to the circuit with the method of least squares. Equivalent circuit elements used in this work will be discussed briefly.

The double layer capacitance (C_d) of the electrode/solution interface is usually modeled as a pure capacitance. The double layer itself is a solution layer, about 10 to 20 Angstroms thick, adjacent to the electrode surface which can be charged due to: 1) nonrandom alignment of dipoles near or at the electrode surface or 2) preferential adsorption of either the anion or cation at the electrode surface. This capacitance is relatively large, on the order of 10^{-5} F/cm², and is strongly potential dependent, but can be treated as constant for potential variations of the order of 5 mV or less (Newman, 1991).

There are two electrochemical phenomena that can be modeled as pure resistance with no reactive component: ohmic electrolyte resistance and Faradaic resistance. The ohmic electrolyte resistance R_Ω is usually linear over the entire range of potential and is simple to analyze. In the case of alkaline aerospace batteries the electrolyte conductivity is quite high so that R_Ω is low. The Faradaic resistance R_p is the resistance to charge transfer across the electrode/electrolyte interface and is also known as the kinetic resistance. It is highly non-linear since the relationship between electrode reaction rate (current density) and interfacial potential difference is exponential, but the exponential relationship can be linearized for potential variations of about 5 mV or less.

The Warburg impedance is caused by concentration gradients in the mass transfer boundary layer (thickness of 100 μm order of magnitude) adjacent to an electrode, has both resistive and reactive components, and increases as frequency decreases. This impedance becomes appreciable when the frequency is low enough that significant depletion of reactants or accumulation of products occurs during the anodic or cathodic half of a sinusoid. The Warburg impedance for an electrode in a large excess (semi-infinite) of solution is

$$Z_w = \sigma / (j\omega D)^{0.5} \quad (1)$$

where D is the diffusion coefficient, ω is the frequency and σ is the Warburg coefficient,

$$\sigma = RT/C_b (nF)^2 \quad (2)$$

R is the gas constant, T the absolute temperature, C_b the bulk concentration, n the stoichiometric number of electrons transferred and F is Faraday's constant (96487 Coulombs/mole electrons).

The phase of the Warburg impedance is -45° and the magnitude is proportional to the inverse square root of frequency. More complex expressions are required when there is not excess solution or when there is more than one diffusing species contributing to the impedance. An exponential relation between concentration and potential (the Nernst equation or something similar) means that this impedance is also highly non-linear but can be linearized for voltage amplitudes less than 5 mV.

Another circuit element that has gained popularity in recent years, especially when the data to be analyzed does not fit simple circuit elements, is the constant phase element (CPE). It has the mathematical form

$$Z_{\text{cpe}} = A(j\omega)^{-n} \quad (3)$$

where A and n are constants that can be fit to experimental data. The impedances R_o , R_p , C_d and

Z_w can be thought of as CPE's where m is a theoretical value. The CPE can be used to account for complex phenomena such as coupled diffusion effects or porosity fluctuations. It is often used as an empirical fitting device and has the disadvantages associated with such tools. However, if the alternative is an equivalent circuit with an excessive number of elements (circuits with 15 or 20 elements have been proposed in some systems without physical explanation of the elements) then the CPE may be an attractive alternative.

Figure 2a shows a simple equivalent circuit that has been used often. C_d is considered parallel to R_f and Z_w , forming an equivalent interfacial impedance that is in series with the R_o . The justification cited is that the first three can only be determined by measurements at an interface. However, since R_f and C_d are double-layer phenomena while Z_w is a diffusion layer phenomena (orders of magnitude thicker than the double-layer), the circuit of Figure 2b seems more physically realistic.

The two preceding equivalent circuits are for smooth planar electrodes. Battery electrodes usually are porous electrodes in which there is pore electrolyte resistance as well as the interfacial impedances discussed in the preceding paragraphs. Figure 2c shows transmission line model that is often used to model porous electrodes, where R_o is the pore electrolyte resistance and Z_i represents the collective interfacial impedances. The impedance of this electrode, when there is no D.C. bias current and no concentration gradients along the pore axis (DeLevie, 1963), is

$$Z_p = \cosh(mL) / (\kappa_{eff} m \sinh(mL)) \quad (4)$$

where

$$m^2 = a / \kappa_{eff} Z_i \quad (5)$$

a is the interfacial surface area per unit volume and κ_{eff} is the effective conductivity of the elec-




Figure 2. Equivalent Circuits used in Impedance Modeling.

trolyte. In the limit of small mL

$$Z_p = Z_1/aL \quad (6)$$

while in the limit of large mL

$$Z_p = 1/\kappa_{eff} m \quad (7)$$

At this latter limit, the phase angle of Z_1 is halved so that double layer capacitance has an apparent phase angle of -45° while semi-infinite Warburg impedance has an angle of -22.5° .

The equivalent circuit for Z_1 used most in this study is shown in Figure 2d, and is similar to Figure 2b except that the Warburg impedance was replaced by a CPE and the ohmic resistance was deleted. Also, almost all the phase angles measured were less than zero (capacitive reactance), and when it is said that a phase angle increases it is referring to the magnitude of the angle.

Numerical Finite Difference Models- The physics and chemistry that govern battery electrode operation can be expressed in the form of coupled differential equations with much greater clarity and flexibility than is possible using equivalent circuit techniques. In particular, complicated phenomena that would otherwise get lumped into CPE's can be modeled in this way. Numerical finite difference solutions for models of charging or discharging batteries abound in the literature. However, these techniques have not been widely utilized to analyze impedance data.

Results and Discussion

Silver/Zinc Cells- A cell consisting of one silver and one zinc electrode from a Yardney 50 Ahr battery was assembled and tested. The reference electrode was an anodized silver wire that was connected to the silver working electrode during cycling. The cell was cycled twice, with discharge at 100% of measured capacity, and the impedance spectrum of each electrode was measured at 100%, 75%, 50%, 25%, and 0% states of charge (SOC).

Figures 3 and 4 respectively are the Bode magnitude and angle plots for the silver electrode during discharge on the second cycle. It shows a trend of decreasing magnitude and phase angle with increasing state of charge at low frequency, reflecting increased mass transfer impedance, although most of the lines cross at 3 mHz. These general trends were observed in both cycles. Figures 5 and 6 are the plots for the zinc electrode during discharge on the second cycle. In this case the fully charged state has the highest impedance magnitude and phase angle. In both electrodes it seems that the bare metal in contact with solution has the higher impedance, while the metal with the fully oxidized surface has the lowest impedance.

Tests were also made with two Yardney 150 Ahr cells. These cells had been cycled at least 100 times, and as received had rest potentials of 1.6V (cell #1) and 0.3 V (cell #2). Impedance measurements were first made for the two cells as received and shown in Figures 7 and 8. Cell number two had a much higher low-frequency impedance. It is thought that the zinc electrode morphology in this cell had deteriorated, reducing the zinc active surface area and increasing the mass transfer limitations. The cells were then charged to 1.8 V rest potential and spectra were again run and are shown in Figures 9 and 10. Charging increased the magnitude of the impedance for both cells but caused the phase angles to become less negative at low frequency. The work reported in the previous paragraph showed that impedance magnitude is highest for bare metal electrodes (the zinc electrode in this case), hence the zinc electrode impedance increases more than the silver electrode impedance decreases during charge. It is also interesting to note that the charged cell has positive phase angles at high frequency. It has been shown in other systems (Keddam, et al., 1981, 1984; MacDonald, 1991) that this can result from non-elementary electrochemical

Porous Ag Electrode

Bode Magnitude Plot





FIGURE 3

Porous Ag Electrode

Bode Angle Plot





FIGURE 4

Porous Zn Electrode

Bode Magnitude Plot




FIGURE 5

Porous Zn Electrode

Bode Angle Plot





FIGURE 6

Impedance of Discharged AgZn Cell

Bode Magnitude Plot




—■— "Good Cell" —◆— "Dead Cell"

FIGURE 7

Impedance of Discharged AgZn Cell

Bode Angle Plot




—■— "Good Cell" —◆— "Dead Cell"

FIGURE 8

Impedance of Charged AgZn Cell

Bode Angle Plot




■ "Dead Cell" ▲ "Good Cell"

FIGURE 9

Impedance of Charged AgZn Cell

Bode Magnitude Plot



■ "Dead Cell" ▲ "Good Cell"

FIGURE 10

reactions. This most likely occurs at the zinc electrode in which the reaction product, zincate ion, is quite soluble in the electrolyte solution.

Figures 11 and 12 compare the experimental results for the impedance of a discharged silver electrode with the best fit to the equivalent shown in Figure 2d at the limit given by Equation 6. The circuit seems capable of following the trends in the magnitude, while the maximum angle discrepancy is about 0.25° . Table 1 gives values for the equivalent circuit parameters. The parameter aC , which is the capacitance per unit volume, is a figure of merit that characterizes the electrochemically active surface area.

Nickel/Cadmium Cells- Impedance spectroscopy was used by Armstrong et al. (1975) and Armstrong and Edmondson (1974) to study cadmium electrodes while Lenhart et al. (1988) have studied porous nickel electrodes. NiCd cell studies have been performed by Sathyanarayana et al. (1979) and Zimmerman et al. (1982).

A cell consisting of a nickel electrode sandwiched between two cadmium electrodes was constructed, and impedance spectra for the nickel and cadmium electrodes were obtained. Figures 13 and 14 compare the spectra for charged and discharged cadmium electrodes. As with the zinc and silver electrodes, the low frequency impedance magnitude and phase angles for the bare metal (charged cadmium) are higher than for the oxidized metal. There was little observed dependence of impedance with state-of-charge for the nickel electrode, which is always in an oxidized state.

Figures 15 and 16 compare the cadmium electrode experimental impedance with the (Figure 2d) equivalent circuit best fit. Of all the electrodes studied, this one seemed to fit the equivalent circuit best. Figures 17 and 18 compare the results for the nickel electrodes, which give a fairly reasonable agreement between experiment and equivalent circuit. There is some

Impedance Silver/Zinc Cells

Bode Magnitude Plot




FIGURE 11

Impedance Silver/Zinc Cells

Bode Angle Plot




FIGURE 12

Porous Silver Electrode - Bode Mag.

Discharged-Zero Cycles




FIGURE 11. ⁶

Porous Silver Electrode - Bode Angle

Discharged-Zero Cycles




FIGURE 12 *b.*

Porous Cadmium Electrode

Bode Magnitude Plot




FIGURE 13

Porous Cadmium Electrode

Bode Angle Plot





FIGURE 14

Porous Cadmium Electrode

Bode Magnitude Plot- 05/17/91




■ Experimental — Model

FIGURE 15

Porous Cadmium Electrode

Bode Angle Plot- 05/17/91



■ Experimental — Model

FIGURE 16

Porous Nickel Electrode

Bode Magnitude Plot- 05/17/91





FIGURE 17

Porous Nickel Electrode

Bode Angle Plot- 05/17/91



■ Experimental — Equivalent Circuit

FIGURE 18

discrepancy in the angle plot although the trends are comparable. The results are markedly different from Lenhart et al (1988), who reported all positive phase angles for porous nickel electrodes over approximately the same frequency range. This may be due to the presence of LiOH in the electrolyte and to differences in electrode manufacture.

It should be emphasized that the fit of equivalent circuits to experiments were obtained by replacing the Warburg impedance, which is based on fundamental electrochemical transport principles, with the empirical constant phase element. Replacement of equivalent circuit models with coupled differential equation models is recommended for future studies. While this approach is much more difficult to implement it is expected to provide a more rigorous understanding of porous battery electrodes.

It is also interesting to note the wide variation in aC values in Table 1. It is possible that the CPE is also accounting for some or most of the double-layer capacitance effects, and that a more fundamental modeling approach will yield double-layer capacitances that do not differ by so many orders of magnitude. However, other workers have also observed order of magnitude differences in capacitance effects between electrodes. For instance, Tiedemann and Newman (1976), using models without empirical components, observed that capacitance effects for porous lead electrodes are two orders of magnitude higher than for porous lead dioxide electrodes. This is because double layer capacitance is a chemical, and not purely an electrical, effect.

Conclusions

1. State of charge estimations can be made using electrochemical impedance techniques. In particular, the low-frequency impedance of metal electrodes is higher in the fully reduced state than in the fully oxidized state.

2. Comparisons between healthy and unhealthy AgZn cells show that, at least in some instances, state of health can be correlated with impedance data. The "dead cell", which presumably failed because of decreased active zinc content and decreased active zinc surface area, had a significantly higher low frequency impedance.

3. Semi-empirical equivalent circuit models were able to fit the experimental data. It is recommended that models incorporating the fundamental coupled differential equations describing the electrodes be solved in future work. Such an approach will be more difficult, and require significant time and resources to initiate, but the results will be more fundamentally satisfying.

References

- R.D. Armstrong and K. Edmondson, *J. Electroanal. Chem. and Interfacial Electrochem.*, vol 53, p. 371 (1974).
- R.D. Armstrong, K. Edmondson and J.A. Lee, *J. Electroanal. Chem.*, vol 63, p. 287 (1975).
- A.J. Bard and L.R. Faulkner, *Electrochemical Methods*, John Wiley and Sons, New York (1980).
- B.A. Boukamp, *Solid State Ionics*, vol 20, p. 31 (1986).
- R. de Levie, *Electrochimica Acta*, vol 8, p. 751 (1963).
- S.J. Lenhart, D.D. MacDonald and B.G. Pound, *J. Electrochem. Soc.*, vol 135, p. 1063 (1988).
- D.D. MacDonald, in *Techniques for Characterization of Electrodes and Electrode Processes*, R. Varma and J.R. Selman, ed., John Wiley and Sons, New York (1991).
- J. Newman, *Electrochemical Systems*, 2nd Ed., Prentice-Hall, Englewood Cliffs, NJ (1991).
- S. Sathyanarayana, S Venugopalan and M.L. Gopikanth, *J. Appl. Electrochem.*, vol 9, p. 125 (1979).
- W. Tiedemann and J. Newman, *J. Electrochem. Soc.*, vol 122, p. 70 (1975).
- A.H. Zimmerman, M.R. Martinelli, M.C. Janecki and C.C. Babcock, *ibid*, vol 129, p. 289 (1982).

Table 1. Equivalent Circuit Parameters.

	<u>Silver</u>	<u>Nickel</u>	<u>Cadmium</u>
aC	212 F	0.021 F	13.25 F
R _f	0.083 Ω	0.0062 Ω	0.044 Ω
A	$2.2 \times 10^{-6} \Omega \text{ s}^{-\text{m}}$	$2.4 \times 10^{-5} \Omega \text{ s}^{-\text{m}}$	$1.7 \times 10^{-5} \Omega \text{ s}^{-\text{m}}$
m	-1.1	-1.7	-1.9



Report Documentation Page

1. Report No.	2. Government Accession No.	3. Recipient's Catalog No.	
4. Title and Subtitle Frequency Response Measurements in Battery Electrodes		5. Report Date January 6, 1992	
		6. Performing Organization Code Department of Chemical Engineering	
7. Author(s) Daniel L. Thomas		8. Performing Organization Report No.	
		10. Work Unit No.	
9. Performing Organization Name and Address The University of Alabama in Huntsville Department of Chemical Engineering Huntsville, AL 35899		11. Contract or Grant No. NAS8-36955-114	
		13. Type of Report and Period Covered Final Report	
12. Sponsoring Agency Name and Address NASA-MSFC Marshall Space Flight Center, AL 35812		14. Sponsoring Agency Code NASA MSFC	
15. Supplementary Notes			
16. Abstract Electrochemical impedance spectroscopy was utilized to investigate the behavior of porous zinc, silver, cadmium and nickel electrodes. State of charge could be correlated with impedance data for all but the nickel electrodes. State of health was correlated with impedance data for two AgZn cells, one apparently good and the other dead. The impedance data was fit to equivalent circuit models.			
17. Key Words (Suggested by Author(s)) Batteries, Impedance, Porous Electrodes		18. Distribution Statement	
19. Security Classif. (of this report)	20. Security Classif. (of this page)	21. No. of pages	22. Price